



Wattage and Amps

Power Setting	Wattage Setting		
Max/Sear	600W 5 Amps	900W 7.5 Amps	1,800W 15 Amps

Based on line voltages registering 120V.

Changing Wattage Setting

The PIC Titanium operates at a default of 1800 watts. If you use the PIC Titanium in a location with limited wattage, you can adjust the PIC Titanium's wattage by pressing **Watts** until you reach the desired wattage.

When Cooking at lower wattages, your cooking time may increase slightly.

1 cup water 2 qt. saucepan	600W	900W	1,800W
	4:15 min.	2:00 min.	85 sec.

Quick Start

- Press **Start** the display will then show a temperature of **375F/191C** and default cook for 1 hour.

Pause

- Press **Pause Clear** once to pause cooking. Display will clear after 45 minutes.

Resume

- Press **Start** to resume cooking.

Stop

- Press **Pause Clear** twice to clear.

Changing Fahrenheit to Celsius

- Press **Prog** once.
- Press **⊕** once to display Fahrenheit.
- Press **⊖** again to display Celsius.
- Press **Pause Clear** to finish.

Adjust Cooking Temperature

Increase/decrease the temperature manually by selecting 1 of the 6 temperature settings, or by pressing **⊕** or **⊖** to adjust the temperature by 5-degree increments.

Easy Temperature Settings

Press Button	Range Temperature	Examples
Low	100°F (38°C)	Warm
Med/Low	175°F (79°C)	Simmer
Med	275°F (135°C)	Steam
Med/High	375°F (191°C)	Stir/Deep Fry
High	425°F (218°C)	Boil/Saute
Max/Sear	575°F (302°C)	Sear

Changing Cooking Time While Cooking

To cook for a specific time or longer than 1 hour. **Ex: 3 hours and 45 minutes.**

- Press **Time** twice to set column one, then press **⊕** 5 times to set for 5 minutes.

Step 1

00:05

- Press **Time** again to set column two, then press **⊕** 4 times to set for 4 minutes.

Step 2

00:45

- Press **Time** again to set column three, then press **⊕** 3 times to set for 3 hours.

Step 3

03:45

The flashing digit is the number being altered.

Stage/Programming Cooking

Program the PIC to cook at different temperatures for different amounts of time. **Ex: High for 5 Min. then Low for 3 Min.**

- Press **Prog** to set the stages.
- Press **High** then press **Time** and then press **⊕** 5 times for 5 minutes at High.
- Press **Low** then press **Time** and then press **⊕** 3 times for 3 minutes at Low.
- Press **Start** to begin cooking.

You can add additional stages by just repeating steps 2 or 3 with your desired temperature and time before pressing **Start**.

Delay Cooking

How to program the PIC to delay cooking. **Ex: Delay cooking for 6 minutes, then cook on High for 3 minutes.**

- Press **Prog** to set the delay.
- Press **Time** then press **⊕** 6 times to delay for 6 minutes.
- Press **Prog** then press **High**. Press **Time** and then press **⊕** 3 times to cook for 3 minutes.
- Press **Start** to begin cooking.